128铜版纸/风琴折 展开尺寸：800x80mm 实际尺寸:80x80mm

For all kinds of music

KA53
磁吸迷你无线音箱

用户手册

尊敬的AWEI用户：

感谢您选用AWEI产品！您的选择对于我们至关重要，这意味着AWEI又增加了一名新用户。希望通过我们的产品和服务，为您带来上佳的体验。也希望您在产品体验过程中，通过官方客户热线、微博、微信、等提出好的意见和建议，帮助AWEI不断完善产品和服务。

如果您在产品使用过程中遇到任何问题，请参照服务流程，方便、快捷地获取帮助。您的支持是我们成长的动力，您的每一次认可和评价都是对AWEI莫大的鼓励。谢谢！

AWEI营销团队

非常感谢您使用AWEI KA53戶外炫光无线音箱，在使用本产品之前，请详细阅读本手册。

附件清单



产品说明图

1. 短按:减小音量
长按:上一曲
2. 短按:暂停/播放/免提通话/挂断
长按:开/关机/拒接来电
双击:蓝牙/TF卡切换
三击:蓝牙模式TWS
3. 短按:增大音量
长按:下一曲
4. TF卡接口
5. Type-C充电口
6. 指示灯

怎样使用

无线扬声器内置循环可充电锂电池。电池电量耗尽后，扬声器将自动关闭。
请及时为扬声器充电。

给无线音箱充电

将充电线的Type-C端插入扬声器的充电端口，另一侧插入充电器或USB充电设备上使用的计算机/其他USB充电设备的USB端口。充电成功后，充电端口下方的指示灯将呈红色LED亮起，扬声器充满电后红色LED灯将熄灭。

重要提示
- 请勿擅自拆卸、修理或改造无线音箱。
- 音箱含有内置锂离子电池，请勿随意丢弃电池或将无线音箱置于火中。
- 请勿将无线音箱置于雨中或潮湿的环境中，以防无线音箱遭到损坏。
- 请不要重复对无线音箱反复充电，以免造成内置锂离子电池加速老化。
- 使用快充功能的充电器给音箱充电时，严禁使用支持快充的一拖几充电线，一边给手机充电，一边给音箱充电。因为市面上有些不合规的一拖几的快充线，同时给多个设备充电会有烧坏设备。

无线配对连接设备

长按⏻按钮打开扬声器的电源，
当听到音效提示音时蓝色指示灯闪烁，表示无线音箱处于等待配对模式将带有无线功能的设备设置为搜索无线设备。
当启用无线功能的设备找到无线设备时，从找到的无线设备列表中选择"AWEI KA53"配对连接。
配对连接成功后会有语音提示"嘟"时，表示无线音箱已连接

怎样使用

TWS对箱立体声播放

- 长按⏻键启动音箱。
- 当两台音箱都处于无线模式时，三击其中一台的⏻键，等待数秒后，播放相应提示音，音响将会进入TWS模式，实现立体声音频播放效果。
- 在手机中搜索"AWEI KA53"并将其与此设备配对。
- 享受您的音乐。
- 如果您不需要TWS模式，三击⏻按钮，您将听到"嘟"的声音，然后扬声器不在TWS模式下。

音乐模式	功 能	按键操作
播放音乐中	增大音量	短按 ＋ 键
	减小音量	短按 － 键
	暂 停	短按 ⏻ 键

暂 停	播 放	短按 ⏻ 键
播放音乐中	上一曲	长按 － 键
	下一曲	长按 ＋ 键

请注意:上述功能适用于所有模式，如无线、TF卡播放。

怎样使用

使用TF卡播放音乐

长按⏻按钮打开扬声器的电源。
将预装有歌曲的TF卡插入音箱的TF卡插槽时，将会播报提示语音"TF卡模式"。无线音箱将自动播放TF卡内歌曲。

提示
在无线播放/TF卡播放之间待机模式下，当无线音箱不使用时，请关闭它以节省电池电量。

常见问题及解决方案

问 题	可能的起因	解决方案
音量过小	音源（平板电脑、手机、笔记本电脑等）的音量太低	调整音源设备的播放音量
	音箱电池电量低或电池已损坏	请为无线音箱充电或更换电池
失音/破音	音箱电池电量低或电池已损坏	请为无线音箱充电或更换电池
没有声音	音源（平板电脑、手机、笔记本电脑等）已关闭	打开音源设备
	无线音箱已关闭	打开无线音箱电源
	无线音箱处于播放暂停状态	按下无线音箱播放按键
无线连接失败	无线音箱可能出现技术故障	重启无线音箱
	无线音箱已与附近音源设备（配对连接过的音源设备）连接	关闭附近其他音源设备无线功能，重新将音源设备与无线音箱配对连接

产品规格

1.蓝牙版本:	V5.3
2.TF卡扩展支持最大容量	32GB
3.电池容量:	800mAh
4.播放时间:	4小时(80%音量)
5.充电时间:	2小时
6.频率响应范围:	80Hz-10KHz
7.蓝牙工作频率:	2.402GHz-2.480GHz
8.蓝牙有效距离:	≥10M
9.充电输入标准:	DC 5V (Type-C)
10.输出功率:	5W
11.支持模式:	免提通话、无线播放、TF卡播放、TWS
12.产品尺寸:	67mm×67mm×49mm (L*W*H)

安全与保养

请阅读以下提示，以帮助延长产品使用寿命，并清楚 保修条款。
★ 保持产品干燥，勿将产品放在潮湿的地方，以免影响产品内部电路；
★ 不要将产品放置在太阳晒射或者高温的地方，高温会缩短电子部件的使用寿命损坏电池，使某些塑料部件变形；
★ 不要将产品放在过冷的地方，以免损坏内部电路板；
★ 不要试图拆开产品，尤其是非专业人员，可能会损坏产品；
★ 不要跌落、强烈震动、用硬体撞击产品，以免损坏内部电路；

安全与保养

★ 不要使用烈性化学制品、清洁剂清洁机器；
★ 不要用尖体在产品表面上乱划，以免损坏外壳和影响外观；
★ 不要对机器连续充电超过10小时，以免影响使用寿命；

如产品不能正常工作，请将其送至AWEI的授权维修机构，工作人员会热心帮您解决问题。

声明：为提高产品性能我们会进行产品升级，本说明内容可能会有所变更，恕不另行通知，敬请见谅。

感谢您的选购！

香港雅乐国际有限公司 监制
深圳市雅乐电子有限公司 出品
厂址：中国深圳市龙华区大浪裕景泰科技工业园

消费者服务热线/传真：
服务热线：400-998-3899
合作邮箱：yale@awei.hk
售后服务：service@awei.hk

获取更多信息请访问：
www.awei.hk

国外社区：
twitter ：https://www.twitter.com/Aweiglobal
facebook ：https://www.facebook.com/aweiproducts
instagram：https://www.instagram.com/awei_official

官方微信查真伪

产品售后服务指南

一、七天包退细则
A. 包退原则：用户在AWEI直属专营店或经AWEI授权的分销店所购买的产品，自购买之日起7天内，产品未受到任何人为或外力的损害而发生的产品质量问题，厂家包退货。
B.退货流程：用户将产品、包装和票据完整地拿到（或自费邮寄到）购买地点给卖家检测——卖家按质保鉴定规则检测，鉴定该产品实属产品质量问题——卖家退还用户购买产品时所付的费用。

二、十五天包换细则
A. 包换原则：用户在AWEI直属专营店或经AWEI授权的分销店所购买的产品，自购买之日起15天内，产品未受到任何人为或外力的损害而发生的产品质量问题，厂家包换货。
B. 换货流程：用户将产品、包装和票据完整地拿到（或自费邮寄到）购买地点给卖家检测——卖家按质保鉴定规则检测，鉴定该产品实有产品质量问题——卖家为用户更换货品并开具新票据。

三、十二个月包修细则
A. 包修原则：用户在AWEI直属专营店或经AWEI授权的分销店所购买的产品，自购买之日起十二个月内，产品未受到任何人为或外力的损害而发生的产品质量问题，厂家包修。
B. 包修流程：用户将产品、包装和票据完整地拿到（或自费邮寄到）购买地点给卖家检测——卖家按质保鉴定规则检测，鉴定该产品有产品质量问题——卖家填写产品质保卡并盖公章——卖家将产品邮寄给厂家维修——厂家维修好邮寄给卖家——卖家通知用户取货。

四、质保鉴定规则
A. 无质保产品：包装盒、收纳袋、耳机夹、耳套等附属部件；不在三包期内的产品；非AWEI授权 或非正规渠道所购买的产品；非AWEI正品；赠品；被人为损害的产品；被外力损害的产品。
B. 质保鉴定：查三包期（以票据为证）——查正品（进AWEI官方网站查防伪编码）——查产品损坏情况（有无明显人为造成的破损、有无被水、火、化学物品或重物损害的痕迹）——查产品质量（在符合产品使用的情况下测试效果是否与产品描述相符）——查购买渠道（限厂家查证）

AWEI产品保修卡（请认真填写完整）

产品型号		条形码	
用户名字		用户电话	
用户住址			
商家名称		商家电话	
商家地址			
购买日期		报修日期	
损坏情况		维修时间	
备注			

For all kinds of music

KA53
Magnetic Mini Wireless Speaker

User Manual

Dear AWEI User,

Thank you for choosing AWEI product. Your choice is crucial for us,which means AWEI has added-gained a new user. Hope that we will bring you good experience through our products and services. Also hope you will put forward good advice and suggestions by official customer hotline, Weibo and Wechat in the process of product experience,which can help AWEI constantly improve product and service.

If you encounter any problems in using products, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to AWEI. Thank you!

AWEI marketing team

Thank you very much for using the AWEI KA53 outdoor colorful light wireless speaker, please read this manual in detail before using this product.

Accessories List

Overview Of Speaker



1. Short press : Volume decrease
Long press : Previous track
2. Short press:Pause/Play
/Handfree calling/Hang up
Long Press:ON/OFF switch
/Reject incoming call
Double press:Pairing/TF switch
Triple press: TWS(Pairing)
3. Short press : Volume increase
Long press : Next track
4. TF card slot
5. DC5V input
6. LED indicator

How To Use

The wireless speaker has a built-in rechargeable lithium-ion battery. Once the battery is depleted, the speaker will automatically shut down.
Please charge the speaker promptly.

Charging wireless speakers

Plug the Type-C end of the charging cable into the charging port on the speaker and the other end into the USB port on the charger or USB charging device used on the computer/other USB charging device. When charging is successful, the indicator light below the charging port will light up red. The red LED light will turn off when the speaker is fully charged.

Important Notes
- Do not disassemble, repair, or modify the wireless speaker without authorization.
- The speaker contains a built-in lithium-ion battery. Do not discard the battery or dispose of the wireless speaker in fire.
- Do not expose the wireless speaker to rain or moisture to prevent damage.
- Do not repeatedly charge the wireless speaker to prevent accelerated aging of the built-in lithium-ion battery.
- When charging the speaker with a fast-charging charger, do not use a fast-charging cable to charge your phone and the speaker simultaneously. Some non-compliant fast-charging cables on the market can damage devices if used to charge multiple devices simultaneously.

Wireless pairing and connecting devices

Press and hold the ⏻ button to turn on the speaker.
When you hear the tone, the blue indicator light flashes, indicating that the wireless speaker is in pairing mode. Set your wireless device to search for wireless devices.
When your wireless device finds wireless devices, select "AWEI KA53" from the list of found wireless devices to pair with.
When pairing is successful, a voice prompt "beep" will sound, indicating that the wireless speaker is connected.

How To Use

TWS speakers stereo playback

- Press and hold the ⏻ button to power on the speaker.
- When both speakers are in wireless mode, triple-click the ⏻ button on one of them. After a few seconds, a notification tone will sound and the speaker will enter TWS mode, enabling stereo audio playback.
- Search for "AWEI KA53" on your phone and pair it with the device.
- Enjoy your music.
- If you don't want TWS mode, triple-click the ⏻ button. You will hear a beep, and the speaker will no longer be in TWS mode.

Music mode	Function	Operation buttons
Playing music	Increase Volume	Short press ＋ key
Playing music	Decrease Volume	Short press － key
Playing music	Pause	Short press ⏻ key
Pause	play	Short press ⏻ key
Playing music	Previous track	Long press － key
Playing music	Next track	Long press ＋ key

Note: The above features are suitable for all modes such as wireless, TF card playback.

How To Use

Use TF card to play music

Press and hold the ⏻ button to turn on the speaker.
When you insert a pre-loaded TF card into the speaker's TF card slot, a voice prompt will be heard, announcing "TF Card Mode." The wireless speaker will automatically play the songs on the TF card.

Tip:
In standby mode between wireless playback and TF card playback, please turn off the wireless speaker when not in use to save battery power.

Common Problems and Solutions

Problem	Possible cause	Solution
Low sound level	Source (Tablet, Mobile phone, Laptop, etc.) volume too low.	Adjust source volume
	Low battery or battery dead	Low battery or replace battery
Sound distorted	Low battery or battery nearly dead	Low battery or replace battery
No sound at all	Source (Tablet, Mobile phone, Laptop.) turned off.	Turn the source on
	Speaker turned off	Turn the speaker on
	Media paused on source	Play media from source
Wireless BT cannot connect	There are short functional obstacles in the product	Restart the speaker
	Product has been connected with other devices	Disable wireless BT of other source devices and search for wireless BT again

Specifications

1. Bluetooth version:	V5.3
2. TF card expansion supports maximum capacity:	32GB
3. Battery capacity:	800mAh
4. Playback time:	4 hours (80% volume)
5. Charging time:	2 hours
6. Frequency response range:	80Hz-10kHz
7. Bluetooth operating frequency:	2.402GHz-2.480GHz
8. Bluetooth effective range:	≥10M
9. Charging input standard:	DC 5V (Type-C)
10. Output power:	5W
11. Supported modes:	Hands-free calling, wireless playback, TF card playback, TWS
12. Product dimensions:	67mm × 67mm × 49mm (L*W*H)

Safety And Maintenance

Please read suggestsions below in order to help prolong the product lifespan and clearly understand the warranty clauses.
★ Keep the product dry, do not put it in humid circumstance to avoid short circuit.
★ Do not expose it to the sunshine or high heat. High heating will shorten lifespan of electronic components, damage battery and deform some plastic parts.
★ Do not put it in cold circumstance to avoid damage to PCB board.
★ Do not attempt to take apart the product, especially non-professionals.
★ Do not fall, vibrate strongly,strike with hard objects, to avoid damage to inner electronic circuit.

Safety And Maintenance

★ Do not use high chemical products,detergent to clean the product.
★ Do not scratch the surface with sharp items to avert damaging the case and appearance.
★ Do not make it charge 10 hours continuously for the sake of lifespan.

If the product can not work properly, please send it to AWEI authorized maintenance agents. Our staff will help to solve the problems for you.

Statement: In order to improve product performance we will upgrade products, the content may change without notice,pls forgive! Thank you for your purchase.

Supervised by H.K. Yale International Co., ltd
Produced by Shenzhen Yale Electronics Co., ltd
Factory Add: 4th Floor, Buidling 2, Yujingtai Industrial Park, Huaxing Road, Longhua District, Shenzhen, China.

Customer service hotline/ Fax:
Hotline: 400-998-3899
Cooperation mailbox: yale@awei.hk
After-sales service: service@awei.hk

For more information please visit:
www.awei.hk

Contact:
twitter : https://www.twitter.com/Aweiglobal
facebook : https://www.facebook.com/aweiproducts
instagram : https://www.instagram.com/awei_official

AWEI WeChat

Products after-sales service

1. 7 Days Refund Policy
A. Guarantee of Refund: Within 7 days since the date of purchase, the manufacturer promises to refund if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artifical and external force damage excluded).
B. Refund Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should refund the money the user paid for the product.

2. 15 Days Replacement Policy
A. Guarantee of Replacement: Within 15 days since the date of purchase, the manufacturer promises to replace if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artifical and external force damage excluded).
B. Replacement Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should replace the product and issue a new invoice to the user. Freight arrangements please check with the shop you contact.

3. Twelve Months Warranty Policy
A. Guarantee of Maintenance: Within twelve months since the date of purchase, the manufacturer promises to offer maintenance service if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artifical and external force damage excluded).
B. Maintenance Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should fill warranty card with offical stamp and send back to manufacturer. After repairing, manufacturer sends the product to the seller and the seller should inform the user to collect it. Freight arrangements please check with the shop you contact.

4. Quality Assurance Identification Rules
A. Quality Assurance is NOT applicable to those items: accessories like packing box, pouch, ear clip and earmuffs; product beyond warranty period; product got from unauthorized agents or informal channels; fake AWEI product; AWEI premium; arificial damaged product; external force damaged product.
B. Quality Assurance Identification Procedure: Check warranty period (by original invoice) —— confirm original product (check security code on AWEI offical website) —— check product damage (clarity artifical damage and external force like water, fire, chemicals or weight crush damages) —— check product quality (to confirm if the testing result is conform to description) ——check buying channel (subject to manufacturer's verification).

AWEI Warranty Card (please fill this carefully)

Model No.		Barcode	
User Name		Tel	
Address			
Seller		Seller Tel	
Seller Add			
Date of Purchase		Date for Maintenance	
Damage Situation		Maintenance Time	
Remark			